

# Refrigerated Vaccine Inside at 2°C to 8°C



## RECEIVING AND UNPACKING STEPS

- 1 IMMEDIATELY** open the cooler and follow the TagAlert receiver instructions. See below for details.
- 2 Compare** the packing list to the contents of the cooler to confirm they match. See below.
- 3 Inspect** the vaccine and report any tampering (e.g., broken seal). See back for details.
- 4 Place vaccine** in appropriate storage immediately upon receipt.
- 5 Repack** the cooler for refurbishing. See back for details.
- 6 Return** the cooler via UPS. See back for details.



### INSTRUCTIONS FOR CONFIRMING PROPER SHIPPING TEMPERATURES

#### Receiver Instructions

- 1. Stop TagAlert® Indicator**  
Press and hold the START & STOP button for 5 seconds until Stop icon ● appears.
- 2. Read Indicator Status**  
✓ Accept: Left arrow ◀ points to Green check mark: Ready for Use.  
✗ Reject: Right arrow ▶ points to Red X and numbers 1, 2 and/or 3 are visible—a temperature alarm has triggered. **QUARANTINE PRODUCT** and call +1-877-836-7123 or your state/local immunization program right away.

T17003135 Rev. A

## TAGALERT INFORMATION

- Remove the TagAlert temperature monitor from the box. The TagAlert is located inside the inner box, next to the vaccine.
- Follow the recipient instructions on the blue card:
  - Stop TagAlert Indicator.** Press and hold the Start and Stop button until the Stop icon appears.
  - Read Indicator Status.** Determine if the appropriate temperature was maintained during transit.
  - TagAlert Monitor Concerns?** Please call **1-877-836-7123**.



**Vaccine should be placed in appropriate storage immediately upon receipt.**



## REVIEW YOUR PACKING SLIP

McKesson Specialty Care Dist.  
8745 Forest Hill Irene, Suite 105  
Olive Branch, MS 38654

**Ship-to:**  
McKesson Specialty Care Dist.  
8745 Forest Hill Irene, Suite 105  
Olive Branch, MS 38654

**Awarde**  
McKesson Specialty Care Dist.  
8745 Forest Hill Irene, Suite 105  
Olive Branch, MS 38654

**Packing Slip**

This is not an invoice

Page 1 of 2

**Provider PIN:** WVA200066

**Delivery Number:** 230684533

**Quality Check Date:** 02/11/2025

Internal use only

NDC	Customer P.O.	Material Description Manufacturer	MFR Lot#	Exp. Date	VFC Doses	317 Doses	State Doses	CHIP Doses	Order Qty	Ship Qty	Unit Price	Extended Price
19515-0810-52 5017406	394261	FLU; SYR; 10-pack (TIV) PED CDC GLAXO SMITHKLINE	AE2J7	06/16/2025	10	0	0	0	10	10	\$15.22	\$152.20
<b>Total</b>									10	10		\$152.20

Verify the **MFR Lot#** and the **Ship Qty** on the packing slip with the contents of the cooler.  
The **Ship Qty** is the total number of vaccine cartons.

# Refrigerated Vaccine Inside at 2°C to 8°C



## WHO TO CALL

### Questions?

Need a UPS Pickup of your EcoFlex cooler?

### CONTACT

**UPS Phone Number:** 1-800-377-4877

7:00AM – 9:00PM EST Monday – Friday

7:30AM – 6:00PM EST Saturday

**UPS Email:** [Healthcaresupport@UPS.com](mailto:Healthcaresupport@UPS.com)

7:00AM – 9:00PM EST Monday – Friday

7:30AM – 6:00PM EST Saturday

**WEB:** [UPS.com/healthcare](https://www.ups.com/healthcare)

**Provide the McKesson Account Number: 20V8R9**



## RETURN YOUR COOLER

PLEASE  
RETURN COOLER  
DO NOT  
DISPOSE



**Step 1:** Open shipper and remove the top PCM gel pack(s).



**Step 2:** Remove the product(s) from the inner corrugated box.



**Step 3:** Ensure the inner corrugated box is back in the EcoFlex shipping system.



**Step 4:** Place the top PCM gel pack(s) back on top.



**Step 5:** Fold in the original outer flaps. Fold in the remaining flaps with return.



**Step 6:** Schedule a pickup with UPS. Contact UPS either by phone or by email.



The return shipping label can be found on the inside flap of your EcoFlex box. For more information, contact [info@coldchaintech.com](mailto:info@coldchaintech.com)

**McKESSON**